

FORM OIL SPRAYER PARTS LIST

Item No.	Qty.	Part Description
1	2	3/4"-10 NYLON 2 WAY LOCK NUT
2	4	WHEEL BEARINGS
3	2	WHEELS
4	2	3/4"- 3 1/2"x 10 BOLT
5	1	1-1/4" CLOSE NIPPLE
6	1	1-1/4" BALL VALVE
7	1	1-1/4" STREET ELBOW
8	1	3/8"x24" DROP TUBE 4457K31 (24")
9	1	PIPE BUSHING (2" MALE - 3/8" FEMALE)
10	1	3/8" STREET ELBOW
11	2	3/8"x2" LONG CLOSE NIPPLE
12	1	3/8" BALL VALVE
13	1	3/8" IN-LINE FILTER
14	1	1/4" FEMALE X 3/8" MALE SWIVEL
15	1	PRESSURE GUAGE
16	1	1/4" TEE
17	1	1/4" CLOSE NIPPLE
18	1	1/4" AIR FILLER VALVE
19	1	1/4" POP OFF VALVE (75 PSI)
20	1	2" STEEL PLUG
21	2	2" BUNG
22	1	1-1/4" BUNG
23	2	1/4" BUNG
24	1	1/4" HOSE x 25' LONG
25	1	WAND NUT
26	1	SPRAY TIP
27	1	WAND STRAINER
28	1	18" WAND
29	1	CERAMIC SEAT SHUT OFF SEAT
30	1	GUNJET SPRAY GUN
31	1	FILTER ELEMENT
32	1	SPRINGS
33	4	3/4" STAR WASHER INTERNAL
35	1	GUN REPAIR KIT
36	1	HOSE, GUN, & WAND ASSEMBLY
37	1	SPRAY GUN & WAND ASSEMBLY
38	1	18" WAND ASSEMBLY (INCLUDES WAND, STRAINER, TIP, & NUT)